

Using the Extron Touch Panel Media Controller - Stafford



Projector Controls


- Hides the projected image
- Freezes the image currently being projected
- Useful when checking something privately on your device
- Powers on the projector and classroom system
- The system is ready when the button turns white



- Shows the projected image
- Shows the projected image
- Powers off the projector
- Allow a moment for the projector to shut down

Projection Source

- Best choice for most classes
- Uses existing instructor Mac to connect to all room resources
- Displays the Blu-Ray player
- Turn the player on from the device itself (if needed)
- Connects a device wirelessly to the projector
- Useful for student presentations; podium Mac preferred for regular use



- HDMI/USB-C connection to hook up own device and have access to all room resources
- Provides additional device connection
- Opens the camera controls menu

Projection Mode

- Applies the selected source to both projectors
- Applies the selected source to the left projector only
- Applies the selected source to the right projector only
- Displays the selected source in the preview window before sending it to a projector
- Plays audio from the selected source without displaying it on a projector




OVER

Camera Controls

Lecture Capture

- Opens the controls for the classroom's PTZ cameras
- Select the front or rear camera before making adjustments


Live Capture Control	What It Does
Rec	Starts the lecture capture recording.
Stop	Stops and ends the recording.
Pause	Temporarily pauses the recording.
Mark	Adds a marker to the recording for later reference.
Cameras Only	Records or displays only the camera feed.
Content Only	Records or displays only the presentation or content source.
S/S =	Displays the camera and content side by side at equal sizes.
S/S Content	Displays the camera and content side by side, with greater emphasis on the content.
S/S Cameras	Displays the camera and content side by side, with greater emphasis on the camera.
PIP Small	Displays a small camera image over the content.
PIP Med	Displays a medium camera image over the content.
PIP Large	Displays a large camera image over the content.
Advanced	Opens additional lecture capture settings.
Close	Closes the lecture capture controls.



Camera Control	What it does
Live Camera Selection – Rear / Front	Selects the camera used for the live recording.
Preview Camera – Rear / Front	Selects the camera shown in the preview
Up / Down / Left / Right	Moves the selected camera in the chosen
Zoom In / Zoom Out	Adjusts how closely the selected camera is
Presets 1–8	Moves the camera to a previously saved
Set	Saves the current camera position as a preset.
Camera Preview	Displays a preview of the selected camera.
LC Preview	Displays a preview of the complete lecture capture
Advanced Settings	Opens additional camera and recording options.
Close	Closes the camera controls.

OVER


Audio Controls



- Mutes the classroom speakers
- Adjusts the volume of the classroom speakers
- Ensure your device's volume is on and the correct audio output is selected





- Adjusts the volume of the wireless mic going to the classroom speakers



Room Controls


- Adjusts the classroom lighting to the presets






- Raises and lowers the right and left projector screens

Phone Conference




- Use the touch panel's phone controls to dial the person you want to call. Once connected, their voice will play through the classroom speakers, and the room microphones will allow them to h ear the students in the classroom.




- Use when you need to temporarily prevent the caller from hearing the room
- Ends the calls

Other Controls



- Shuts down classroom system
- Always use this when finished with the room



- Opens instructions for using classroom equipment