

Using the Extron Touch Panel Media Controller - Tome 115



Projector Controls




- Hides the projected image
- Freezes the image currently being projected
- Useful when checking something privately on your device
- Powers on the projector and classroom system
- Red = right projector
- Green = left projector
- Black = both projectors

- Shows the projected image
- Shows the projected image
- Powers off the projector
- Allow a moment for the projector to shut down

Projection Source


- Displays the Blu-Ray player
- Turn the player on from the device itself (if needed)
- Displays the classroom document camera
- Turn the camera on/off from the device itself
- Best choice for most classes
- HDMI/VGA hookup to the podium



- Jacks on the front of the desk requiring the appropriate cable that allow connection to the podium
- Connects a device wirelessly to the projector
- Useful for student presentations

Projection Mode

- Applies the selected source to both projectors
- Plays audio from the selected source without displaying it on a projector



- Applies the selected source to the left projector only
- Applies the selected source to the right projector only

OVER


Camera Controls

cameras

- Opens the controls for the classroom's PTZ cameras
- Select the front or rear camera before making adjustments

- Selects the camera you want to control
- Confirm the correct camera is selected before making adjustments

- Moves the selected camera to a saved position
- Use a preset for quick, automatic camera placement




- Manually moves the selected camera
- Use for small positioning adjustments

- Adjusts how closely the camera frames the subject

- Closes the camera controls
- Returns to the main touch panel screen

Audio Controls




- Mutes the classroom speakers

- Adjusts the volume of the classroom speakers
- Ensure your device's volume is on and the correct audio output is selected


Audio Settings

- Opens the audio settings for the classroom's PTZ cameras

- Controls the volume when conferencing
- Better to adjust the volume within Teams/Zoom



Room Controls



- Raises and lowers the right and left projector screens

Other Controls

Shutdown System

- Shuts down classroom system
- Always use this when finished with the room

Help

- Opens instructions for using classroom equipment